



EXTREME RANGE CLAMP 100-5X
FOR USE WITH PCS-1, PCS-2, PCS-4, PRS-5, AND PRS-7 REPAIR STANDS

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u>
1	1002	Jaw cover set (includes circlips)	1
2	1020-2	Handle spring pin	2
3	1004-2	Clamp handle	2
4	1022	Handle stud	1
5	1027	Clevis pin .312 x 1.875	1
6	1018	Lock housing spring pin	1
7	1016	Set screw 8-32	1
8	1015	Lock housing cover	1
9	1014	Quick release lever	1
10	1017	Quick release lever spring	1
11	1019	Acme rod	1
12	1025	End cap	1
13	1008-5	Rotating shaft	1
14	107-2	Clevis pin c-clip	1
15	107-3	Clevis pin washer	2
16	1023	Side plate	1
17	1029	Socket head cap screw 10-32	1
18	1026	Centering cap	1
19	1005A	Sliding jaw weldment	1
20	1006A	Main body weldment	1
21	1024	Partial nut support	1
22	1004-1	Flat washer 7/16 x 5/8	1