



## **HOME MECHANIC REPAIR STANDS**

### **PCS-1 AND PCS-2 (pre-6/96)**

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u>
1	138-2	Handle grip	1
2	103-2	Clamp handle	1
3	101-2	Movable jaw	1
4	107-CS	Clevis pin	2
5	107-2	Circlip	2
6	468G	Jaw cover set (includes circlips)	1
7	467-1	Circlip	4
8	110B	Linkage	1
9	111A-6	Spring	1
10	112A-CS-R	Linkage pivot	1
11	113A	Thin nylon lock nut 5/16 - 18	1
12	112B-R	Linkage pivot knob	2
13	102-2	Rotating shaft and jaw	1
14	190B	End cap for horizontal tube	1
15	191-2G	Positioning knob and shaft	1
16	195	Support tube, upright, and flange (PCS-2 only)	1
17	185-2	Upper support (PCS-1 only)	1
18	226-2	Thin nylon lock nut 1/4 - 20 (PCS-1 only)	2
19	187-2D	Bolt 1/4 - 20 x 2 (PCS-1 only)	2
20	187-2C	Curved leg (PCS-1 only)	2
21	190-2	Leveling end cap (PCS-1 only)	2
22	104	Work Tray complete (optional)	2