



SINGLE ARM STAND PRS-6 AND BENCH MOUNT STAND PRS-7 (post-6/96)

Ref. No.	Part No.	Description	Qty.
1	138	Handle grip	1
2	103S	Handle	1
3	107S-2	Pin with circlips and washers	2
4	101-3	Movable jaw	1
5	468B	Jaw cover set (includes circlips)	1
6	102-5	Rotating shaft	1
7	108S-2	Pin with circlips and washers	1
8	117S-1	Eyebolt	1
9	118S	Adjusting barrel	1
10	121S	Adjusting barrel pivot	1
11	136	Nut 1/4 - 28	2
	122S	Linkage assembly (#8-11)	
12	116S	Cap screw	2
13	117A	Locking body and handle	1
14	943-2/944	M5 x 30 Socket head cap screw with 5mm nut	1
15	117A-1	Swing handle	1
16	749-1	1/2" Bearing washer TRA815	1
17	748-1	Needle bearing	1
18	749-2	1/2" Bearing washer TRB815	1
19	117A-2	Spacer	1
20	212S	1/2 - 13 Hex jam nut	1
21	149	Tapered sleeve	1
22	943-1/944	M5 x 25 Socket head cap screw with 5mm nut	2
23	939-1	Composite top tube	1
24	185R	Upright and flange (PRS-6 only)	1
25	131S	Nut 1/4 - 20 (PRS-6 only)	4
26	132S	Washer 3/16" cut (PRS-6 only)	4
27	194B	Base (PRS-6 only)	1
28	194C	End cap (PRS-6 only)	1
29	133S	Button head cap screw 1/4 - 20 x 7/8 (PRS-6 only)	4
30	195R	Bench mount weldment (PRS-7 only)	1

NOTE: Because of design changes made to the 100-5C Clamp, replacement of a #102-5 Rotating shaft manufactured prior to Jan. 2001 also requires replacement of the #103S Handle. A #102-5 manufactured prior to Jan. 2001 will have a protrusion (approx. 21mm x 9mm x 8mm) on the shaft. A #102-5 manuf. after Jan. 2001 will not have this protrusion.