



## WALL MOUNT PRS-8

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u>
1	102-8	Rotating shaft	1
2	468B	Jaw cover set (includes circlips)	1
3	101-8	Movable jaw	1
4	107S-2	Pin with circlips and washers	1
5	116S	Cap screw 5/16 - 18 x 3/8	2
6	113A	Thin nylon lock nut 5/16 - 18	1
7	112A	Linkage pivot	1
8	111A-6R	Spring	1
9	110B	Linkage	1
10	108A-2	Pin with circlips and washers	1
11	103B	Handle	1
12	110S	Ball knob	1
13	111S	Handle	1
14	109S	Spring pin 5/32 x 1-1/4	1
15	191	Positioning knob and shaft	1
16	196	Wall Mount Weldment	1
17	198	Washer 5/16	2