

## REPAIR STAND MOUNT TRUING STAND TS-5

Ref. No.	Part No.	Description	Qty.
1	952	Bracket	1
2	943-3	Socket head cap screw M5 x 35	2
3	950	Spacer	2
4	131S	Hex nut 1/4 - 20	2
5	949	Gauge	1
6	259	Knob and shaft 1/4 - 20 x 7/8	1
7	494	Gauge spacer	1
8	943-2	Socket head cap screw M5 x 30	1
9	951	Main collar set	1
10	1109	Knob and shaft 1/4 - 20 x 1-3/4	1
11	944	Hex nut 5mm	1

