

REPAIR STAND MOUNT TRUING STAND TS-5

| Ref. No. | Part No. | Description | Qty. |
|----------|----------|---------------------------------|------|
| 1 | 952 | Bracket | 1 |
| 2 | 943-3 | Socket head cap screw M5 x 35 | 2 |
| 3 | 950 | Spacer | 2 |
| 4 | 131S | Hex nut 1/4 - 20 | 2 |
| 5 | 949 | Gauge | 1 |
| 6 | 259 | Knob and shaft 1/4 - 20 x 7/8 | 1 |
| 7 | 494 | Gauge spacer | 1 |
| 8 | 943-2 | Socket head cap screw M5 x 30 | 1 |
| 9 | 951 | Main collar set | 1 |
| 10 | 1109 | Knob and shaft 1/4 - 20 x 1-3/4 | 1 |
| 11 | 944 | Hex nut 5mm | 1 |

